

# Grassbank

One step closer...

## Inner Arch Ideas

Our fibre glass front inner arch finishers can be seen fitted in the first picture here. Note the two front straps which we use to attach to the front bumper chassis end bolts. The arches also pickup on the M8 stud bracket under the chassis leg and lastly two fixings onto the bottom edge of the wheel arch. They need trimming to fit and you may need to trim the bottom edge of the bonnet so that it closes past them. Don't worry about close fits... the fact that you will have fitted something here is a bonus and they do a great job of keeping the muck out anyway.

We sell a simple 6" wide arched fibreglass panel which we use to make-up the inner arches. They need trimming to fit and we tack-glue them in place before running fibreglass matt into the seams. A simple rubber 'Top Seal' can then be used to completely close the gaps if you want. E.g. <https://www.woolies-trim.co.uk/product/1364/mud-flap-push-on>

The box sections seen in the last picture here are available too and are used to pick up on the bonnet rest rubbers to make things nice and solid when the bonnet closes. Other solutions are available but not from us...

